EASTERN
TABLETOP

Lithium Battery Induction Warmer

USER MANUAL

EASTERN TABLETOP

Thank you for choosing the Eastern Tabletop Lithium Battery Induction Warmer

MODEL #9015PB



MODULES

- Lithium Battery Induction Warmer
- Rated Operating Power: 25.2V
- Charger: 29.2V8A

EASTERN TABLETOP

Important Notice

Thank you for purchasing a EASTERN TABLE TOP INC product. Please carefully read this user guide before use, follow the instructions for correct use, and keep it properly.

Under the premise of complying with laws and regulations, our company reserves the right of final interpretation of this document and all related documentation for this product. Please refer to the latest official announcement for any updates, revisions, or discontinuation.

The following situations are not covered by the warranty: damage to the appearance of the product after use; self-disassembly or repair; product performance failure due to human factors; damage caused by force majeure such as natural disasters, lightning, accidents,etc.

& Warnings

Before using this product, please carefully read and understand the safety information. Failure to follow these safety instructions may result in electrical shock, potentially leading to serious injury, or property damage.

Fire. This product is an electrical device that can generate heat. Do not cover the product or place items on it to avoid fire. Please keep away from flammable items when using this product.

Explosion. Do not use an incompatible charging device. Do not attempt to jump start, charge, or discharge the produce if it is damaged or frozen. Never charge or discharge the product outside its operating temperature range. Never over charge or over discharge the product. Never exceed the maximum charging currents of the product. Never incinerate the product.

Electrical Shock. This product is an electrical device that can deliver a shock and cause serious harm. Do not soak it in water or get it wet.

Technical Specifications


Lithium Battery Induction Warmer

Model	Dimension (mm)	Battery Material	Battery Capacity	Rated Voltage	Max Power	Charge Voltage	Charge Current
9015PB	17" x 14½" x 2½"	LiFePO4	32Ah	25.2V	200W	29.2V	8A

Working Temperature (°F)	122°F	131°F	140°F	149°F
Working Time (hours)	5.5 hours	5 hours	4.5 hours	4 hours
Charge Time	3.5 - 4 hours			

EASTERN TABLETOP

Cooker Function Description




1.Temperature	2.Battery Capacity	3.Power	4.Power Switch	5.Temperature Level Indicators	6.Power Level Control "+ -"Button

Temperature Control

Temperature Level	Description	LED Indicator
Level 1	122°F	
Level 2	131°F	
Level 3	140°F	
Level4	149°F	

Backside



EASTERN TABLETOP

Warranty Information

EASTERN TABLE TOP INC warrants this product ("Product") to be free from defects in material and workmanship for a period of two years from the date of purchase (the "Warranty Period").
During the Warranty Period, EASTERN TABLE TOP INC will, at its option, repair or replace any defective product. Replace- ment parts and products shall be new or in good condition and warranted for the remainder of the original warranty period.

EASTERN TABLE TOP INC's liability is limited to repair or replacement. To the maximum extent permitted by law, EASTERN TABLE TOP INC shall not be liable for any special, indirect, consequential or punitive damages, including lost profits, property damage or personal injury. This warranty is in lieu of all other warranties, stated or unstated. If applicable law provides for a warranty that cannot be excluded or modified, this warranty applies to the maximum extent permitted by law.

This warranty is provided only to the original purchaser of the Product from EASTERN TABLE TOP INC or an authorized. Dealer and is not transferable. To make a warranty claim, the purchaser must (1) request and obtain a Return Material Authorization.(RMA) number by email; and (2) mail the Product and receipt to the designated address. Do not return the product without authorization.

The original purchaser is responsible for all packaging and shipping costs.

This warranty is void in the event of: (1) misuse, improper handling, or operation under extreme conditions; (2) improper installation or maintenance; (3) unauthorized modifications; (4) disassembly or repair by anyone other than EASTERN TABLE TOP INC; or (5) defects reported after the warranty period.

This warranty does not cover: (1) normal product; (2) cosmetic damage that does not affect function- ality; or (3) missing or damaged serial number.

Hassle-Free Warranty Conditions:

These conditions apply only to Products within the Warranty Period. If the time since the purchase date exceeds the Warranty Period or if any of the above conditions apply, the warranty will be void. Please return the product with the appropriate documentation.

With Receipt: 2 Year Free, warranty period starts from the purchase date.

Without Receipt: 2 Year Free, warranty period starts from the date corresponding to the serial number.

Important Safety Warnings

Operation. Operating environment temperature range is -4°F(-20°C) to 140°F(60°C). Charging environment temperature range is 14°F (-10°C) to 122°F(50°C). Do not operate outside the recommended temperature ranges.

Storage. Recommended storage temperature range is -4°F(-20°C) to 140°F(60°C). Do not exceed 140°F(60° C) under any circumstances. To achieve the best service life, store at 25°C and maintain a state of charge above 70%. Self-discharge rate is less than 1%/month. Storing the battery for more than 6 months without charging is not recommended.

Charging. This product is attached with a 29.2V8A lithium-ion battery adapter. Do not charge this product with an incompatible adapter. For optimal performance, we recommend using only the29.2V8A lithium-ion battery adapter. If using a third-party adapter, as they can pose severe electri- cal risks, leading to personal injury, property damage, shortened product life, and product failure.EASTERN TABLE TOP INC is not responsible for the safety of using accessories or adapters not approved by EASTERN TABLE TOP INC. If the product overheats, deforms, swells, or emits smoke or odor during charging, stop using it immedi- ately and contact support.

Handle this product with care. Bumps and knocks may damage this product. Do not use dam-ged products, including products with cracked casings. Moisture and liquids may cause short circuits and electric shocks in this product. Do not spill liquids on this product or the included adapt- er. If there is liquid on the surface of this product or it becomes wet, do not use this product. Please wipe this product dry with a dry towel to ensure that there is no liquid that can cause short circuits or electric shocks before using it. Store the product in a dry place. Do not modify this product with- out authorization. Disassembly of this product may cause electric shock or property damage. Modi- fication or disassembly must be performed by professionals.

Cleaning. When cleaning this product, be sure to disconnect the power cord. Use a dry or slightlydamp towel to wipe the surface. Do not use high-pressure water to clean this product.

Proposition 65. This product including its battery, and related accessories may contain chemicals known to the State of California to cause cancer, birth defects, and other reproductive harm.

Medical Devices. This product may emit electromagnetic fields. It contains magnetic components that may interfere with pacemakers, defibrillators, or other medical devices. If you suspect this product is interfering with medical equipment, stop using it immediately and consult your doctor.

Disposal. This product must be recycled or disposed of separately and not with household waste.
Discarding this product in household trash is illegal under state and federal environmental laws. Please take this product to a local battery recycling center.

Explosive Environments. Obey all signs and instructions. Do not operate this product in any area with a potentially explosive atmosphere, including gas stations or areas containing chemicals or particles such as grain, dust, or metal powders.

Radio Frequency Interference. This product complies with regulations regarding radio frequency emissions. Radiation from this product may adversely affect the operation of other electronic devices, possibly causing them to malfunction

FQA

1. **How long will a fully charged battery last?**
When operating at maximum power, this product can run continuously for 4 hours; at minimum power, it can run for 5.5 hours.

2. **What is the battery lifespan?**
We use lithium iron phosphate(Lifepo4) batteries, which have a cycle life of over 2,000 cycles.

3. **What is the charging time?**
It takes 3.5 to 4 hours to fully charge using the adapter supplied with this product.

EASTERN TABLETOP

4. What is the warranty?
This product comes with a 2-year free warranty starting from the date of purchase.

5. Is it safe to charge overnight?
Please monitor the charging status of this product; disconnect the power immediately once it is fully charged, and do not leave it charging unattended overnight.

6. Can I use while plugged-in?
We do not recommend using this product while it is charging.

7. Can I cook on it?
The maximum power of this product is insufficient for cooking food; it can only be used to keep food warm.

8. Can I use any charger?
To ensure safety, please use the adapter supplied with this product; do not use an incompatible adapter.

9. How do I space them on a buffet?
When using multiple products simultaneously, please ensure a separation distance of at least 20-30 cm.

10. Can these units be used outdoor in the rain?
This product contains an internal battery; do not use it outdoors in the rain or in the presence of water to prevent electric shock.



Easterntabletop.com

Toll-Free: 1-888-422-4142
Phone: 718-240-9595
sales@easterntabletop.com

Factory | Warehouse | Design Studio
50 Ingham Ave, Bayonne, NJ 07002